




# CLIFF


## PUSHBUTTON KNOB CS12



Part No. **CP3427**  
**CS12 PUSHBUTTON KNOB GREY**



Part No. **CP3431**  
**CS12 PUSHBUTTON KNOB RED**



Part No. **CP3433**  
**CS12 PUSHBUTTON KNOB BLACK**